



PLEASE NOTE THAT WE HAVE INSTALL VIDEOS FOR MANY MODELS ON GOOGLE VIDEO AND YOUTUBE.COM. SEARCH UNDER "WIND DEFLECTOR"

# Wind Deflector Sebring 2001 to 2006 Installation Guide

**START BY PUTTING YOUR TOP DOWN**

**STEP 1:**  
WHEN YOUR WIND DEFLECTOR WAS SHIPPED WE NEEDED TO STORE THE FRONT BRACKETS FACING IN.



**STEP 1 CONT:**  
LOOSEN ALL THREE SCREWS, TURN THE BRACKET SO IT FACES OUT AND THEN TIGHTEN. REPEAT TO THE OTHER SIDE.



**STEP 2: UNFOLD THE BOTTOM PANELS AND PLACE THE WIND DEFLECTOR IN THE BACK SEAT AREA. KEEP THE TOP PANEL FOLDED DOWN**



YOUR WIND DEFLECTOR HAS FOUR BRACKETS TWO IN THE FRONT AND TWO IN THE BACK THAT ATTACH TO THE TRIM PANEL.

**STEP 2 CONT THE FRONT BRACKETS REST ON THE TOP OF THE SIDE TRIM PANEL.**



**STEP 2 CONT: THE BACK BRACKETS ARE HOOKS THAT ATTACH TO THE SIDE TRIM PANEL NEAR THE BACK SEAT.**



**STEP 3: THERE ARE SNAPS ON EACH SIDE OF YOUR QUARTER TRIM PANEL (YOU CAN STILL ATTACH YOUR BOOT COVER TO THIS SNAP)**



**STEP 3 CONT: THE BACK BRACKET HAS A STRAP WITH A FEMALE SNAP WHICH ATTACHES TO THE MALE SNAP ON THE QUARTER TRIM PANEL.**



**STEP 3 CONT: THE SNAP STRAP IS BEST ATTACHED FROM UNDERNEATH THE WIND DEFLECTOR. ATTACH THE SNAP STRAP ON BOTH SIDES OF WIND DEFLECTOR.**



**STEP 4:**  
NOW ATTACH THE HOOK STRAP TO THE  
BOTTOM OF THE TRIM PANEL AT THE  
BOTTOM OF THE BACK SEAT.



**STEP 4 CONT;**  
START BY SLIDING THE HOOK UNDER THE TRIM  
PANEL AND THEN ATTACHING THE BUCKLE.  
REPEAT TO THE OTHER SIDE.



**STEP 5:** NEXT ATTACH THE BLACK SNAP  
HOOK TO THE ANCHOR SYSTEM AT THE  
MIDDLE OF YOUR BACK SEAT (2001 MODEL  
CARS SEE LAST PAGE OF INSTRUCTIONS)



**STEP 5 CONT;** SLIDE THE BLACK SNAP  
HOOK INTO THE ANCHOR WITH THE SNAP  
FACING DOWN. ONCE ATTACHED TO THE  
ANCHOR PULL ON THE STRAP TO SECURE  
IN PLACE.



**STEP 6:** ATTACH THE SIDE  
STRAPS TO THE BUCKLES  
UNDER THE FRONT  
BRACKETS AND THE BLACK  
SNAP HOOKS TO THE  
BUCKLES IN THE MIDDLE OF  
WIND DEFLECTOR



**STEP 6 CONT:**  
PULL THE FOUR  
STRAPS TIGHT AND  
YOU ARE READY  
TO GO DRIVING



THE FOUR BOTTOM STRAPS WILL  
LOOK LIKE THIS WHEN ATTACHED.  
TWO STRAPS GO DOWN FROM  
BELOW FRONT BRACKETS AND TWO  
GO DOWN TO THE ANCHOR SYSTEM  
FROM THE MIDDLE OF THE WIND  
DEFLECTOR.



**FOR SEBRING 2001 OWNERS YOU MAY NOT HAVE THE BABY SEAT ANCHOR SYSTEM DEPENDING ON WHAT MONTH YOUR CAR WAS MADE. SO YOU NEED TO ATTACH THE BLACK SNAP HOOK TO THE HOLE IN THE TRIM PANEL JUST BELOW YOUR BACK SEAT ON EACH SIDE**

**STEP 5: IF YOUR SEBRING DOES NOT HAVE THE ANCHOR SYSTEM YOU WILL ATTACH THE BLACK SNAP HOOK TO HOLES IN YOUR TRIM PANEL. THE HOLES ARE LOCATED BELOW THE BACK SEAT**



**STEP 5 CONT: THE BLACK SNAP HOOK SLIPS INSIDE THE HOLE AND THEN PULL UP. NOW ATTACH THE TWO STRAPS TO THE BUCKLES IN YOUR WIND DEFLECTOR.**



**WHEN YOU HAVE THE STRAPS IN PLACE IT WILL LOOK LIKE THIS PHOTO.**



**YOUR WIND DEFLECTOR STORES IN YOUR TRUNK BUT REMEMBER THAT YOU HAVE TO REVERSE THE FRONT SIDE BRACKETS**



**TO REVERSE THE FRONT BRACKETS. TURN THE THUMB SCREWS TO LOOSEN. THEN TURN THE BRACKET TO FACE INSIDE AND REINSTALL THE THUMB SCREWS.**



**NOW WITH YOUR WIND DEFLECTOR UP YOU ARE READY TO GO DRIVING!**



**NOW YOU ARE READY TO LOVE THE DRIVE  
[WWW.LOVETHEDRIVE.COM](http://WWW.LOVETHEDRIVE.COM)**