




We have our video install guides on
our website and on youtube.com
Also feel free to call or email us if
you have any questions
1-855-457-5683
information@lovethedrive.com

BMW 6 2011 to 2014

Love The Drive Wind Deflector

Install Guide

Start by lowering your top and moving your front seats forward. The wind deflector attaches to your BMW 6 using holes designed for a Windstop. There is 1 hole on each side trim panel behind front seats. There are 2 holes between the headrests in the rear seat.



Start by extending one barrel bolt and locking the bolt by turning the handle down.



Loosen the thumb screws on the rear bracket (1 turn counter clockwise (Lefty = Loosey) . Turn both of the rear brackets so they face out. Then tighten the thumbscrews by turning them Clockwise till they are snug (Righty = Tightly)



Lower the wind deflector into the back seat. Insert the extend barrel bolt into the hole on the trim panel, on the opposite side from which you are standing.



Lower the windstop till the barrel bolt on your side aligns with the hole in the trim panel. Slide the bolt into the hole and turn the handle down so it locks the bolt into place.



Lower the back of the windstop into the holes between the rear seat head rests. To remove the windstop just reverse the order of the steps.



To easily store your windstop in the trunk you will need to lower the barrel bolts. Loosen (do not remove) the thumbscrew at the bottom of the barrel bolt. Remove the top 2 thumbscrews. Slide the bolt down and replace the thumbscrews in the top holes. Reverse the steps to move the bolt to the up position.



When not in use, your BMW 6 windstop can be stored in the trunk. Please use the storage bag provided when storing your wind deflector.

