



Roadster Solutions, LLC



Installation of S2K Travel Boot Cover

Step one – Open your trunk.

Step two – Place the rear edge of the S2K Travel Boot Cover into the drain well area forward of the trunk seal and close the trunk lid.

Step three – Attach the TENAX snaps inside the cockpit.



Step Four – Tuck in the sides.



If you have any questions, please don't hesitate to call us toll free at 1-877-862-0585 or email us at Sales@RoadsterSolutions.com.