

## **Shoulder Belt Pad Set**

These instructions have been prepared by Roadster Solutions, LLC, specifically for the Shoulder Belt Pads. No methods other than those specified in these instructions are to be used to install the Shoulder Belt Pads. Carefully read all instructions before proceeding with this installation.

## **INSTALLING THE SHOULDER BELT PADS.**

- 1. The side of the Shoulder Belt Pad where the outer flap is <u>attached</u> should be toward the occupant. See photo below.
- 2. Pull open and fold the outer flap back (loop side).
- 3. Fold back the inner flap (hook side).
- 4. Place the shoulder belt between the two flaps.
- 5. Unfold the inner flap (hook side).
- 6. Unfold the outer flap over the inner flap and press firmly.

Installation is complete.



