

Z4 (E85) Clear WindBlocker (with Leather Covered Roll Hoops) installation Instructions

KIT CONTAINS:

1. Center Panel Outboard Brackets (2)
2. Acrylic Center Panel (1)
3. Alcohol wipes (2)

IMPORTANT PRE INSTALLATION NOTES:

1. Thoroughly clean the installation areas with the enclosed alcohol wipes prior to adhering the brackets to the vehicle.
2. Proper installation requires the brackets and mounting surfaces to be at least 70 degrees F. This can be achieved by running the heater on high with the top up for 10-15 minutes or by using a hair dryer to gently heat the mounting surfaces. Do not over-heat the mounting surfaces or damage to the paint may occur.
3. Installation may require leaning over the painted surfaces of the vehicle. Take precautions to protect the paint from belt buckles, buttons, snaps, etc.

INSTALLING THE BMW Z4 WIND JAMMER:

1. Clean the mounting surface on both roll hoops with one of the enclosed alcohol wipes. Peel the (red) backing from the tape on one of the Center Panel Outboard Brackets. Either bracket will fit either side.
2. Orient the Center Panel Outboard Brackets. *The "notch" allows clearance for the gasket around the bottom of the roll hoop.* Starting at the bottom, align the Center Panel Outboard Brackets with the parting line around the roll hoops and work bracket upward while maintaining alignment with the parting line.
3. Once the Center Panel Outboard Bracket is mounted to the roll hoop, apply firm pressure to the bracket for 10-15 seconds to secure the tape. Make sure all tape edges are in contact with the roll hoop.
4. Repeat steps 1 through 3 for the opposite side.

CARE AND CLEANING:

- The WindBlocker panel is designed to be a semi-permanent installation and can be removed for occasional cleaning or storage, however due to the design, it is not recommended that the parts be constantly removed and reinstalled. The Center Panel Brackets are to be permanently installed.
- If you remove the Center Panel, store it in the foam shipping envelope, soft towel or flannel pillow case.
- To clean the Center Panel we recommend Mequiar's Mirror Glaze Clear Plastic Detailer #18 or any quality Plastic Cleaner.
- **DO NOT USE SOLVENT, AMMONIA, OR ALCOHOL BASED HOUSEHOLD GLASS AND SURFACE CLEANERS ON THE PANEL OR DAMAGE TO THE ACRYLIC MAY OCCUR.**